°Control Controller
(Blue LED display)

To View Min/Max Vaccine Temperature

STEP 1
RUNNING LOAD TEMPERATURE
The number shown on a **resting display** is the **running load temperature**

STEP 2
TO VIEW MAX. LOAD TEMP.
Press and quickly release button

STEP 3
TO VIEW MIN. LOAD TEMP.
Press and quickly release button

TO RESET MIN/MAX LOAD TEMP.
Press and hold and buttons for 3 seconds

WHEN RESET THE 'RUNNING LOAD TEMPERATURE' IS ALWAYS DISPLAYED

To View Min/Max Air Temperature
If you have reset your min/max load temp. you will need to return to step 1, if not continue to step 4.

STEP 4
TO VIEW RUNNING AIR TEMP.
Press and quickly release button

STEP 5
TO VIEW MAX. AIR TEMP.
Press and quickly release button

STEP 6
TO VIEW MIN. AIR TEMP.
Press and quickly release button

TO RESET MIN/MAX AIR TEMP.
Press and hold and buttons for 3 seconds

WHEN RESET THE 'RUNNING LOAD TEMPERATURE' IS ALWAYS DISPLAYED