

USER GUIDES

How to unlock the controller





UNLOCK THE CONTROLLER

Before using any function on the controller. You will need to unlock the controller...



1 Press and hold the navigation button for 3 seconds



2 Hold until all dashes appear and the main screen appears

